



(2) UNPUNCHED STUDS.  
MEMBER SIZES AS REQ'D  
PER DESIGN.

ATTACH TOP & BOTTOM  
TRACK & WEBS USING:  
(2) #10-16 SCREWS  
@ 16" o.c.

WEB STIFFENER OR CLIP ANGLE  
AS REQ'D PER DESIGN.

6" LONG SECTION OF STUD  
ATTACHED TO JAMB  
w/(4) #10-16 SCREWS.

JAMB & JACK STUDS.  
MEMBER SIZES & QUANTITY  
AS REQ'D PER DESIGN.

CRIPPLE STUDS.

(1) #10-16 SCREW  
TYP. EACH FLANGE  
HEAD TRACK.  
MEMBER SIZES AS  
REQ'D PER DESIGN.

**CLARKWESTERN**  
DESIGN

East Coast - Atlanta, GA  
20 Mansell Court East, Suite 350B  
Roswell, GA 30076

West Coast - San Diego, CA  
2035 Corte Del Nogal, Suite 165  
Carlsbad, CA 92011

Toll Free Phone: 877-832-3206

BACK TO BACK HEADER  
LOAD BEARING HEADER