



NOTE:
THIS FASTENER MUST BE INSTALLED THROUGH THE CLIP LEG AND THE TRACK FLANGE TO THE STRL ANGLE.

CONNECTION TO STRL ANGLE

To see a complete library of Dietrich CAD detail drawings,
<http://www.dietrichmetalframing.com/precad.htm>