



This symbol can be used for ironer model F20075 electric










This symbol can be used for ironer model F20075 gas



This symbol can be used for ironer model F20075 steam

Legend of connection symbols

- | | | | |
|---|-----------------------------|---|--|
|  | Main electrical connection |  | Compressed air inlet connection |
|  | Gas inlet connection |  | Steam inlet connection (optional on washers) |
|  | Exhaust vent connection |  | Steam condensate return connection |
|  | Cold water inlet connection | | |

All clearances shown are minimum recommended