

**BLOCKING NOTE:**

PLACE SOLID BLOCKING AT ENDS OF FLOOR SYSTEM, ADJACENT TO ALL OPENINGS, AND AT 10'-0" o.c. MAX.

MIN. 18 GA RUNNER TRACK  
SOLID BLOCKING @ 10'-0" o.c.  
MAX. MAKE RUNNER TRACK 8" LONGER THAN JOIST INSIDE SPACING. CLIP FLANGES OF TRACK 4" FROM EACH END. BEND TRACK AT CLIPPED FLANGES.


ATTACH BLOCKING TO JOISTS w/(2)#10-16 SCREWS IN EACH FLANGE AS SHOWN.

(1)#10-16 SCREW IN EACH JOIST FLANGE

**STRAP NOTE:**

TOP STRAP NOT REQ'D. IF CONTINUOUSLY ATTACHED RIGID SHEATHING IS USED. TEMPORARY BRACING OF TOP FLANGE DURING CONSTRUCTION MAY BE REQ'D.

1-1/2" x 20 GA. STRAPPING ON TOP & BOTTOM OF JOISTS. (STRAPPING TO START, END, & SPLICE AT SOLID BLOCKING)



BRIDGING RECOMMENDATIONS	
SPANS	ROWS REQUIRED
UP TO 14'	ONE ROW @ MID-SPAN
14' TO 20'	TWO ROWS @ THIRD POINTS
20' TO 26'	THREE ROWS @ QUARTER POINTS



**CLARKWESTERN**  
DESIGN

East Coast - Atlanta, GA  
20 Mansell Court East, Suite 350B  
Roswell, GA 30076

West Coast - San Diego, CA  
2035 Corte Del Nogal, Suite 165  
Carlsbad, CA 92011

Toll Free Phone: 877-832-3206

**JOIST BRIDGING**

1-1/2" x 20GA. STRAP WITH  
RUNNER TRACK BLOCKING